



17800 N. 85th St.
Scottsdale AZ 85255-9603

www.TASER.com

Activation Instructions

The following are the activation instructions for your TASER C2. This activation process will only need to be successfully completed one time to prepare your TASER C2 for use. Prior to activation, please take the time to review the manual and watch the instructional DVD that came with your TASER C2. The 5 digit activation code shown below must be entered to activate your unit.

Your activation code is: _____

This code is for TASER C2 serial number: _____

DO NOT LOAD THE CARTRIDGE PRIOR TO ACTIVATION. If you have already done this, please see your instruction manual on how to safely remove it.

STEP 1 **Slide the safety cover OPEN and verify that the RED light is on.** If you do not see a RED light, please contact TASER support at 888-827-3788.

STEP 2 **Enter the first digit of your activation code, by pressing the trigger button the corresponding number of times.** Example: If your activation code starts with a 7, press the trigger button 7 times.

STEP 3 **Then, CLOSE the safety cover completely. This registers the entered digit into the unit.**

STEP 4 **Now, OPEN the safety cover and repeat steps 2 through 4, for the remaining digits of your activation code.**

STEP 5 **After entering all five digits, slide the safety cover to the OPEN position and verify that a GREEN light is blinking.** The light will turn solid GREEN within 45 seconds.

The GREEN light indicates that the code was entered correctly and your TASER C2 is now activated.

If the GREEN light does not come on, remove the battery, wait 5 seconds, re-insert the battery and start over at STEP 1. You may also press the trigger button 12 times to reset your device, allowing you to start over at STEP 1.

If you have difficulty activating your unit, contact **TASER Customer Support** at **888-827-3788**.